

Order #XXXXX - MOD-1410 Assembly




Steps:


- 1) Attach base plate [1] to vertical extrusion [2].
- 2) Slide Counter Bottom [3] over vertical [2].
- NOTE: The counter bottom will be "free floating" until counter top is attached.
- 3) Connect horizontals [4] to vetical [2].
- 4) Place counter top on assembled pedestal base; attach to [3] using bolts provided
- 5) Attach horizontal extrusion [5] to vertical [2].
- 6) Connect vertical extrusions [6] & [6A] to lower horizontal [5].
- 7) Attach upper horizontal [5A] to lower frame assembly.
- 8) Plug power cord into power source.

Plugs into inside of counter to supply power for USB chargers.











WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


www.classicexhibits.com






General Setup Instructions

- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.



Hex Tool - Essential for Assembly



Part Identification - Numbering

Base Plate & Extrusion Connection













Cleaning & Packing

- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all setscrews and locks during disassembly





Extrusion & Lock Connection

Engaged Lock

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

866.652.2100

WARNING

DO NOT USE POWER TOOLS

LADDERS OR LIFTS MAY BE REQUIRED

ALL CONNECTIONS MUST **BE TIGHTLY SECURED**

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

866.652.2100