General Setup Instructions


- •The setup instructions are created specifically for your configuration.
- •Setup instructions are laid out sequentially in levels, including exploded views and a logical series of steps for assembly. We encourage you to study the instructions before attempting to assemble your exhibit.


Cleaning and Packing

- •Use non-abrasive cleaners when cleaning extrusions or ECO Glass inserts.
- •Use mild cleaners and soft materials such as cotton to clean all laminates.
- •Keep exhibit components away form extreme heat and long exposure to sun light. This will prevent warping and fading.
- •Retain all packing material for ease of re-packing. This protects the exhibit components and keeps each part organized.


Disassembling

•When disassembling exhibit, tighten all setscrews to prevent loss of hardware in the shipping process.







Hex Tool for Assembling Exhibit



Numbering Instructions for Setups/Packing



Inline Connection between Extrusions





Baseplate Connection for Vertical Extrusions



ECO-48C COUNTER COMES ASSEMBLED

Steps:
1) Attach Graphic to front, using Velcro.





eco ∕systems[™] SUSTAINABLE EXHIBITS