



Order #XXXXX TF-506 - 10'x10' Hybrid Inline







General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all set screws and locks during disassembly.



Hex Tool - Essential for Assembly




Part Identification - Numbering




MARNING

DO NOT USE POWER TOOLS



Spline Connection




Base Plate & Extrusion Connection




LADDERS OR LIFTS MAY BE REQUIRED



ALL CONNECTIONS MUST BE TIGHTLY SECURED



Extrusion & Lock Connection




Engaged Lock







Top View of Each Level




Level 1 (Bottom level)




Level 2




Level 3



Level 4




Level 5




Setup Hardware





Top View of Each Level

















Setup Hardware



ĀERO


Using Your Setup Instructions

The Aero Setup Instructions are created specifically for your configuration. The instructions include an exploded view of the frame which is sequentially labeled. We encourage you to review the instructions before attempting to assemble your exhibit.


Connections are kept very simple; no tools required. Everything assembles with push-button connectors.


Cleaning and Packing Your Display


- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



Connections are made by holding the button down and sliding the red tube into opposing tube until button locks into the hole of the opposing tube. To disassemble, push button and pull or twist extrusions apart.












Order #XXXXX Attachments

Steps:

- 1) Attach light atop assembled backwall aero frame (see *Light Connection* detail)
- 2) Attach wings to assembled backwall aero frame (see A10 Clamp Detail)
- 3) Attach round graphic to assembled backwall aero frame (see Graphic Attachment detail)









Order #XXXXX MOD-1331 Pedestal Assembly

Qty.

Item

Description

Base Plate

48" Vertical Extrusion


25" Vertical Extrusion


38" Vertical Extrusion

Steps:

- 1) Attach lower verticals to base plate using bolts.
- 2) Attach upper vertical to lower vertical.
- 3) Attach shelf supports [6] to vertical [2].
- 4) Velcro attach shelf atop of shelf supports [6].
- 5) Attach flange plates atop verticals [4,5].
- 6) Set counter atop supports and secure in place. Refer to detail.
- 7) Attach graphics to post. Refer to detail.
- 8) Attach monitor mount to post. Refer to detail.
- 9) Attach round graphic to verticals using screw caps. Refer to detail.

A10 Clamp Detail







of counter into holes on flange plate


Wing Nut


and secure with wing nuts.











When assembled

